

FLAT CAP



Flores
Patterns

Dimensions:

Size: 590 - 620 mm/ 23.22 x 24.4 inch

Print the file with the ratio:

- 590mm/ 23.2 in - Print ratio 98.33%
- 600mm/ 23.62 in - Print ratio 100%
- 610mm/ 24.01 in - Print ratio 101.66%
- 620mm/ 24.4 in - Print ratio 103.33%

Materials:

- 01 Leather Button: 22mm / 0.86 inch (Position top of hat)
- 01 Snap Button: 5mm/ 0.19 inch (Position G1, G2)
- Rubber Bands Sewing: 76x26 mm/ 2.99x1.02 inch (Position G5a)
- The inner lining fabric has the same size as the pattern
- Use leather with a thickness of 2 - 2.5mm / 0.079 - 0.098 inch

Notes:

- Print the pattern in A1 or A4 size at 100% scale
- If using A4, Letter size, combine the pieces into a pattern like A1 size
- Look at the image for more details on the positions
- Attach Snap Button to G1
- Sew G1 - G1a - G1b
- Sew G2 - G2, attach Snap Button (at the same time G2 lining)
- Sew G2 - G3 (at the same time G3 lining)
- Sew G3 - G4 (at the same time G4 lining)
- Sew G5 - G1- G1a - G2 - G3 - G4
- Sew G4 - G4, G5a to G5 - G4 (Note: Stretch the Rubber Bands Sewing when sew)
- Attach Leather Button

Note: You can purchase other accessories such as lining and back strap for the hat depending on your preference.

20mm

1 inch



Instructions:

Preparation Notes

Step 1: Print and Cut the Pattern

Print the pattern on A1 or A4 paper at 100% scale.
If using A4 paper, tape the pieces together to form a full pattern.
Cut all leather and lining pieces according to the pattern.

Step 2: Mark and Label the Pieces

Clearly label all pattern pieces (G1 to G5a).
Mark the locations for snaps, leather button, rubber band sewing, and seam lines.

Assembly Instructions

Step 1: Creating the Cap Crown

Attach the Snap Button to G1 at the marked position.
Sew G1 to G1a, then attach G1b to complete the base structure.
Join the two G2 pieces together, aligning the edges, and attach them to G1.
At the same time, install the Snap Button on G2 while sewing.

Step 2: Sewing the Cap Panels

Sew G2 to G3, making sure to attach the inner lining for a clean finish.
Sew G3 to G4, again sewing the lining at the same time for proper structure.
Make sure the edges are smooth and reinforced.

Step 3: Attaching the Side Panels & Rubber Bands

Sew G5 to G1, then attach G1a, G2, G3, and G4.

Sew G4 to G5, attaching G5a at the same time.

Stretch the Rubber Bands when sewing G5a to G5 and G4, ensuring flexibility.

Secure the stitching with a reinforced backstitch.

Step 4: Attaching the Top Leather Button

Position the Leather Button at the top of the cap.

Secure it by stitching through the inner lining for stability.

Final Adjustments

Check Stitching: Ensure all seams are reinforced and secure.

Edge Finishing: Use a burnishing tool to smooth out rough edges.

Test the Fit: Try on the cap and make adjustments if necessary.

BONUS

Handbag Pattern



Open the link or paste it in your browser to access a Drive folder with the handbag pattern files



https://drive.google.com/drive/u/0/folders/1aR6wlqbWRpyU_i_82OM8w1oA68M9no-E